




# Saturn

## **Task Chair**

Assembly and User Guide



STN50HA model shown for illustration purpose only

## Assembly Instructions

---

### Step 1

Take the **gas lift** and drop into the centre of the **base**

---

### Step 2

Now pick up the **seat** and slot into position on the **gas lift**

---

### Step 3

Now slot the **back** into the **seat** and tighten the wheel once the back has been inserted.

---

## User Guide

---

### Standard Mechanism

The standard mechanism allows the backrest angle to be adjusted with the ability to lock in position.

The back angle can be adjusted by lifting the rear lever on the right hand side of the chair to achieve the desired position, the desired position can be set and locked in place by releasing the lever.

### Seat Height

Adjust height by lifting up the front lever on the right hand side of the chair whilst adding or removing weight from seat. Release the lever to lock position.

### Height Adjustable Arms

*Selected models only\**

Arm height may be adjusted using the trigger situated on the outside of the armrest.

### Back Height

To adjust the height of the back, whilst sitting in the chair, turn the hand wheel on the right hand side of the chair anti-clockwise to release and then raise back to the required position before turning the hand wheel clockwise to lock into position.

